

# Oxy K 30 HW/HS Oxygen Self Rescuer



ST-3478-2003



ST-3475-2003

Oxy K 30 HS - Shoulder strap version



ST-682-2002

Oxy K 30 HW - Wall mounted version

Oxy K 30 HW/HS should be carried when toxic gases can be present or the atmosphere can be oxygen deficient.

Oxy K 30 HW/HS is an oxygen self-rescuer, independent of the ambient air, which uses chemically-bound oxygen.

A quick starter cartridge provides an instant oxygen supply on donning.

Special features of the hood version: The hood provides head, face and eye protection against smoke and heat. It allows for verbal communication, an important component for leaving dangerous situation. The unit is suitable for people wearing glasses and is easy to don and breath.

Oxy K 30 HW/HS is suitable for use in:

- transportation (railway, hazardous material)
- shipping
- sewage
- tunnelling

- drilling platforms
- petrochemical

Oxy K 30 HW/HS is up to 10 years free of maintenance and service.

The hood version is available in the following versions:

**Wall mounted version: (HW)**

- Since disassembly from the wall and opening of the unit will take place in one step, the unit ensures a quick operational readiness.
- It can be positioned ready for use on walls along escape routes.

**Shoulder strap version: (HS)**

- Can be installed in vehicles or carried by potential users.

Our service to you: We will dispose damaged, opened, used or expired oxygen self-rescuers for you.

## TECHNICAL DATA

Duration (min) according to DIN 58639 (breathing rate 35 L/min)	30	
Duration (min) (breathing rate 10 L/min)	120	
Inhalation- / exhalation resistance (hPa) (breathing rate 35 L/min)	5,0	
Inhalation temperature (°C)	max. 55	
Service indicator	readiness for use immediately visible from the outside	
Housing	electrically conductive	
Temperature classification	T4	
Approval	according to DIN 58639; SOLAS, MED denping	
Weight (kg)	<b>HW</b>	<b>HS</b>
- unopened	approx. 3,5	approx. 2,8
- in use	approx. 2,5	approx. 2,2
Dimensions (mm)	227 x 265 x 118	210 x 260 x 105

## ORDER LIST

Oxy K 30 HW	(wall mounted)	6304600
Oxy K 30 HWT	(training unit, wall mounted)	6304601
Oxy K 30 HS	(shoulder strap)	6304700
Oxy K 30 HST	(training unit, shoulder strap)	6304701



## SUBSIDIARIES

### AUSTRALIA

Dräger Safety Pacific Pty. Ltd.  
Notting Hill Vic 3168  
Tel +61 3 92 65 50 00  
Fax +61 3 92 65 50 95

### FRANCE

Draeger Industrie S.A.  
67025 Strasbourg Cedex  
Tel +33 388 40 76 76  
Fax +33 388 40 76 67

### NETHERLANDS

Dräger Safety Nederland B.V.  
2700 AH Zoetermeer  
Tel +31 79 344 46 66  
Fax +31 79 331 62 26

### SPAIN

Draeger Safety Hispania S.A.  
28034 Madrid  
Tel +34 91 358 02 44  
Fax +34 91 729 48 99

### CANADA

Dräger Canada Ltd.  
Mississauga, Ontario L5N 6P9  
Tel +1 905 821 8988  
Fax +1 905 821 2565

### GREAT BRITAIN

Draeger Safety UK Ltd.  
Blyth, Northumberland NE24 4RG  
Tel +44 16 70 35 28 91  
Fax +44 16 70 35 62 66

### SINGAPORE

Draeger Safety Asia Pte. Ltd.  
139950 Singapore  
Tel +65 68 72 92 88  
Fax +65 67 73 20 33

### USA

Draeger Safety, Inc.  
Pittsburgh, PA 15275  
Tel +1 412 787 8383  
Fax +1 412 787 2207

### P.R. CHINA

Beijing Fortune Draeger  
Safety Equipment Co., Ltd.  
Beijing 101300  
Tel +86 10 80 49 80 00  
Fax +86 10 80 49 80 05

### MEXICO

Draeger Safety S.A. de C.V.  
Querétaro, Qro México  
Tel +1 412 787 8383  
Fax +1 412 787 2207

### REP. OF SOUTH AFRICA

Dräger South Africa (Pty) Ltd.  
Bryanston 2021  
Tel +27 11 465 99 59  
Fax +27 11 465 69 53

Dräger Safety AG & Co. KGaA  
Revalstrasse 1  
23560 Luebeck, Germany  
Tel +49 451 882 0  
Fax +49 451 882 2080  
[www.draeger-safety.com](http://www.draeger-safety.com)