

# Dräger REGARD Master Control card

A system Master card which supervises up to 99 input channels. Offers common, single and voting alarms and a remote system reset input.



D-15086-2009

The Dräger REGARD System Master card is used when other cards within the system required unique addresses. All voting, grouped and common alarm status are repeated by the Master card. The Master card can be utilised to Automatically or Copy system configurations to and from a programming PC. Additional Master cards (Xtra) can be installed into a system to give additional voting, grouped or common alarms.

## FEATURES AND BENEFITS

- Voting/Grouped alarm outputs
- Common alarm outputs
- Fully configurable
- Simple operation
- Password protected
- Up to fifteen Xtra Master cards per system



ST-390-2004

Dräger REGARD Master

## TECHNICAL DATA

Control card	Local alphanumeric display Front panel push buttons Front panel LED's
Inputs	RS 485 (internal) Remote reset
Outputs	R1, R 2, and R 3 alarm relays
Power Supply	24 V DC,125 mA
Communications	Internal system highway using RS 485
Approvals	Tested to EN 50270 for EMC directive ATEX II (2)G Acc. to Directive 94/9/EC
Safety Integrity Level	SIL2 certified by exida (IEC 61508)

## ORDER INFORMATION

Dräger REGARD Master	42 05 702
Dräger REGARD Master (DMT)	42 06 307
Dräger REGARD Master (ATEX)	42 06 708

**HEADQUARTERS**

Dräger Safety AG & Co. KGaA  
Revalstrasse 1  
23560 Lübeck, Germany

[www.draeger.com](http://www.draeger.com)

**SYSTEM CENTERS****P. R. CHINA**

Beijing Fortune Draeger Safety  
Equipment Co., Ltd.  
A22 Yu An Rd, B Area,  
Tianzhu Airport Industrial Zone,  
Shunyi District, Beijing 101300  
Tel +86 10 80 49 80 00  
Fax +86 10 80 49 80 05

**GERMANY**

Dräger Safety AG & Co. KGaA  
Revalstrasse 1  
23560 Lübeck  
Tel +49 451 882-2794  
Fax +49 451 882-4991

**FRANCE**

Dräger Safety France SAS  
3c route de la Fédération, BP 80141  
67025 Strasbourg Cedex 1  
Tel +33 3 88 40 59 29  
Fax +33 3 88 40 76 67

**SINGAPORE**

Draeger Safety Asia Pte Ltd  
67 Ayer Rajah Crescent #06-03  
Singapore 139950  
Tel +65 68 72 92 88  
Fax +65 65 12 19 08

**UNITED KINGDOM**

Draeger Safety UK Ltd.  
Blyth Riverside Business Park  
Blyth, Northumberland NE24 4RG  
Tel +44 1670 352 891  
Fax +44 1670 544 475

**USA**

Draeger Safety, Inc.  
505 Julie Rivers, Suite 150  
Sugar Land, TX 77478  
Tel +1 281 498 1082  
Fax +1 281 498 5190